



TYPE K/J THERMOMETERS 800004 & 800007

Although mini sized, light weight and inexpensive, these units provide extremely accurate and reliable temperature measurement with all the versatility and range of type K & J thermometers. Features relative, min/max/ave temperature, hold, and touch tone buttons. Results are displayed on a large 1¼" x 1¾" LCD. An adjustment allows the user to easily calibrate to ice point or any other standard. Model 800007 will read and display results from two probes simultaneously and track the difference between them (T1-T2). Come ready to use with a 9V battery and beaded wire probe (2 probes for 800007). Dim: 5¼" x 2¼" x 1¼" (130 x 56 x 38 mm). Weight: 6 oz (170 g).



With NIST traceable certificate of compliance 800004C and 800007C

OPTIONAL ACCESSORIES

- 800060~97 Type K & J Thermocouple Probes
- 840090 Water Resistant Instrument Pouch
- 840092 Bench-Top Tripod
- 840093 Field Tripod
- 850000 Rubber Boot



Probe	Range	Res.	Accuracy	Operating Environ.	Storage Environ.
Type K	-200 ~ 1370°C & -328 ~ 2498°F	0.1°C	±0.05% rdg + 0.7°C, 1.4°F when inside the range of 23± 5°C, < 80%RH OR 0.01% of reading + 0.03°C per each ° C outside the specified range of 23± 5° C or 73± 9°F	5°C to 40°C (41°F to 104°F), RH <80%	10°C to 60°C (14°F to 140°F), RH <70%
Type J	-200 ~ 1050°C & -328 ~ 1922°F				