



WBGT HEAT STRESS METER 800036

Government organizations such as OSHA have set recommended heat stress limits for various activities. WBGT (Wet Bulb Globe Temperature) provides the most accurate determination of the heat stress index based on the cumulative effect of air temperature, air movement, relative humidity, and radiant heat. WBGT Heat Stress Meter 800036 is a light-weight meter compact enough to carry anywhere to avoid heat exhaustion in public health, sports, military and industrial activities. Highly accurate readings with a typical response time of only 15 seconds. Provides settings for both indoor and outdoor activity and includes an audible alarm, adjustable to your WBGT threshold. Comes with tripod screw and RS232 computer interface. Globe diameter 1.6" (40 mm). Meter Dim: 10" x 2x 1 1/4" (255 x 50 x 30 mm). Weight: 4 oz (126 g).

OPTIONAL ACCESSORIES

- 840052 Software
- 840054 Cable
- 840092 Bench-Top Tripod
- 840093 Field Tripod



	Range	Resolution	Accuracy
WBGT	0~50°C, 32~122°F	0.1	±2°C indoor, 3°C outdoor (-15~40°C) otherwise ±2.5 indoor, 3.5°C outdoor
Air Temperature (TA)			±0.6°C
Globe Temperature (TG)	0~80°C, 32~176°F		±2°C (15~35 °C)
Relative Humidity (RH)	0~100%		±3%(10~90%) otherwise ±5%