

# CTT-SERIES

## CAP TORQUE TESTER

The CTT-10 Digital Cap Torque Tester is used to measure the open and close effort or force to move a cap such as a jar or a soft drink bottle cap. Use for machine setting in production line automation.

### FEATURES:

- Solid 1.5Kg base
- 1,500 Reading internal memory
- Multiple measuring mode  
(Live tracking, peak, peak-to-peak)
- PC connect via USB
- Wireless Printing  
(With optional extra Bluetooth mini printer)
- Data/Diagram display mode
- Available in either 2, 5, 10 and 20N-m capacities



### SPECIFICATIONS:

<b>Accuracy</b>	±0.3% FS
<b>Resolution</b>	0.01N-m, 1N-cm, 0.1kgf-m, 0.01lb-f, 0.1lbf-in
<b>Selectable Units</b>	N·m, N·cm, KgF·cm, LbF·ft, LbF·in
<b>Display</b>	Matrix LCD with LED backlight
<b>Overload Capacity</b>	120% FS
<b>Measuring Mode</b>	Track, Peak, First Peak, Preset, Double Peak
<b>Data Memory</b>	1,500 Readings
<b>Power</b>	3.6 VDC 1600mAH Ni-MH rechargeable batteries
<b>Battery Life</b>	Approx 16 Hours per charge
<b>Charger / Adapter</b>	USB: input 110~240VAC