

The *RAINEW* TIPPING BUCKET RAIN GAUGE



Made in the USA

RainWise, the world leader in tipping bucket rain gauges, presents the *RAINEW*.

Mount this gauge out in your yard and record rainfall inside the house.

The 8" diameter collector meets NWS specifications for statistical accuracy. Every time the bucket tips, a count is transmitted to the indoor display and the gauge empties. **You never have to empty the gauge.** Each tip of the bucket shows one hundredth of an inch on the indoor LCD display. The display will indicate up to 9.99" of rain. A button on the counter lets you reset to zero after each rainfall. Installation to the plug-in counter is a cinch. The long-life lithium counter battery is included.

The *RAINEW* collector has a lifetime guarantee. The counter is guaranteed for one year.

Housing:	High Impact Polypropylene, UV Inhibited
Transducer:	Tipping bucket of specially formulated plastic for low surface tension
Switch:	Dry reed switch.
Output:	Less than 0.1 sec. switch closure.
Capacity:	6 to 24 VDC @ 500ma
Resolutions available:	0.01 inches
Accuracy:	2 % at 1.5" per hour

The RainWise® RAINEW Wireless Rain Gauge

This gauge design eliminates the normal wire connection from the rain gauge to the indoor display. The battery operated transmitter operates up to 300 feet away. Just locate the gauge in an open area and read the rainfall amount on the indoor display. The 8" diameter collector meets NWS specifications for statistical accuracy. Every time the bucket tips, a count is transmitted to the indoor display and the gauge empties. You never have to empty the gauge. Each tip of the bucket shows one hundredth of an inch on the indoor display.

- New Design for 2007.
- 300 ft* Wireless Range.
- Battery Operated.
- Meets NWS specifications.
- Lifetime guarantee on the collector.

The RAINEW WIRELESS rain gauge requires two "AA" batteries for the Transmitter, 3 "AA" cells and a alkaline button battery (included) for the LCD receiver/display. The electronics and enclosure were redesigned and improved for Spring 2007. The RAINEW collector has a lifetime guarantee. The transmitter, receiver, counters and switches are guaranteed for a year. Both recorders have a keyhole slot in the back for wall mounting.

* Specified range based based on unobstructed line of sight. Typical range through one wall is usually 100' to 200'.



The RainWise® Wired Rain Gauges

RAINEW 111 Tipping Bucket Wired Rain Gauge

The 8" diameter collector meets NWS specifications for statistical accuracy. Every time the bucket tips, a count is transmitted to the indoor display and the gauge empties. You never have to empty the gauge. Each tip of the bucket shows one hundredth of an inch on the indoor LCD display. The display will indicate up to 9.99" of rain. A button on the counter lets you reset to zero after each rainfall. Installation to the plug-in counter is a cinch. The long-life alkaline counter battery is included. Mount this gauge out in your yard and record rainfall inside the house.

- Self emptying
- 60 feet of cable included
- Lifetime collector warranty



RAINEW 211 Tipping Bucket Dual Counter Wired Rain Gauge

The 8" diameter collector meets NWS specifications for statistical accuracy. Every time the bucket tips, a count is transmitted to the indoor display and the gauge empties. You never have to empty the gauge. Each tip of the bucket shows one hundredth of an inch on the indoor LCD display. Installation to the plug-in counter is a cinch. Mount this gauge out in your yard and record rainfall inside the house.

- Redesigned for Spring 2007
- Self emptying.
- Dual Displays.
- Lifetime collector warranty

The dual displays allow you to track both individual events and keep an annual running total. The dual counter requires 3 "AA" alkaline batteries and two button cell batteries. The button cell batteries are included and will last for several years.

