🛞 agreto

www.agreto.com

AGRETO Grain Moisture Tester GFM+

Applications:

- Portable Moisture Tester for grains, corn and many other crops
- For farmers and contractors
- Ideal for use on machines

Technical details:

- Rugged casing for mobile employment
- Sample size 80 ml
- Measuring curves for 41 crops
- Testing the whole grain no milling necessary
- Automatic temperature correction
- Spring-loaded indicator in the cap
- Large backlit LCD display
- Foil keypad
- Measuring curves can be simply re-calibrated
- Power supply with two 9 V batteries, sufficient for a whole season
- Measuring range of 5-40 %
- Resolution 0.1 %
- Accuracy +/- 0.5 %
- Menu-driven operation
- Building up averages
- Automatic shutdown
- Scope of delivery: tester, carrying bag, batteries, manual

Benefits:

- Safety during harvesting, warehousing and selling
- High accuracy because of big sample size, compressing the sample and temperature correction
- Easy to use
- Measurement result within seconds
- Sturdy technology



Grains:

Alfalfa Barley Beet Buckwheat Canary Clover purple Clover white Corn low moisture Corn hight moisture Dactyl Fescue Flax (Linseed) Lentils Lupins yellow Millet Mustard Navy Beans Oats Peanuts Spanish Peas Fodder Peas Green

Peas Yellow Phleum Popcorn white Popcorn vellow Papseed (Canola) **Rice long Rice medium** Rye Rye grass Safflower Sorghum (Milo) Soybeans Spelt Sunflower Oil Sunflower Stripe Triticale Wheat Durum Wheat hard red spring Wheat hard red winter Wheat white

AGRETO electronics GmbH • Pommersdorf 11 • 3820 Raabs • AUSTRIA • Tel. +43 2846 620 60 • Fax +43 2846 620-69 Email: office@agreto.com • Homepage: www.agreto.com • Commercial register: 397160i, Jurisdiction: Krems