

SIGFOX INTEGRATED HUMIDITY & TEMPERATURE SENSOR

daviteq

SKU: WSSFC-ATH

SIGFOX NODE INTEGRATED HUMIDITY & TEMPERATURE WSSFC-ATH



WSSFC-ATH-H1.PNG



WSSFC-ATH is the Sigfox Integrated Ambient Humidity & Temperature Sensor, it utilises Digital capacitance humidity sensor to deliver high accuracy and stable measurement. The sensor probe comes with Integral type for the most applications, while the Remote type sensor with cable allows customer to install the sensor in applications where the sensor probe and wireless transmitter part need to be separated. The sensor will transmit data in kilo-meters distance to Sigfox basestation. WSSFC-ATH can support all regions of Sigfox network in over the World, RC1, RC2, RC3, RC4, RC5, RC6, RC7. Some typical applications are environment monitoring for office, warehouse, data-center, hospital, agriculture...



SIGFOX READY

Device are best operating performance on the SIGFOX network



10 YEAR BATTERY

Ultra-low power sensing technology from Daviteq with Ultra-low power wireless technology allow the sensor can last up to 10 years with a 2 x AA Type battery.



HIGH ACCURACY & STABLE

Digital sensor with factory-calibration



SINTERED FILTER

Allow sintered filter to protect sensor in hash environment

Sigfox Wireless Sensor for Monitoring Humidity and Temperature in Datacenter



WSSFC-ATH-H2.PNG

DAVITEQ TECHNOLOGIES INC

No.11 Street 2G, Nam Hung Vuong Res., An Lac Ward, Binh Tan Dist., Ho Chi Minh City, Vietnam

+84.28.6268.2523 / 6268.2524

info@daviteq.com

www.daviteq.com

JAN-2021

| Doc No: WSSFC-ATH-DS-EN-10

1/4

SPECIFICATION

SENSOR SPECIFICATION :	
Sensor	Digital type, factory calibrated, output both Humidity & Temperature values
Sensor Type	Integral or Remote type with cable
Humidity measuring range & accuracy	0 .. 100 %RH, +/- 2.0%
Humidity resolution	0.1%
Temperature measuring range & accuracy	-40 .. + 85 oC, +/- 0.2 oC
Temperature resolution	0.1 oC
Sensor Filter	20um Alloy sintered filter
Sigfox SPECIFICATION:	
Sigfox zones	select RC2-RC3-RC4-RC5 or RC1-RC6-RC7
Antenna	Internal Antenna 2.67 dbi
Battery	02 x AA Type 1.5VDC, working time up to 10 years (depends on configuration)
RF Module complies to	CE, FCC, ARIB
Working temperature	-40oC..+60oC (using Energizer Lithium Ultimate AA battery)
Dimensions	H137xW73xD42
Net-weight	250 grams
Housing	Polycarbonate & POM plastic, IP67

Sigfox Wireless Sensor for Monitoring Humidity and Temperature in Greenhouse



WSSFC-ATH-H3.PNG

Sigfox Wireless Sensor for Monitoring Humidity and Temperature in Warehouse



WSSFC-ATH-H4.PNG

DAVITEQ TECHNOLOGIES INC

No.11 Street 2G, Nam Hung Vuong Res., An Lac Ward, Binh Tan Dist., Ho Chi Minh City, Vietnam

+84.28.6268.2523 / 6268.2524

info@daviteq.com

www.daviteq.com

JAN-2021


| Doc No: WSSFC-ATH-DS-EN-10

SYSTEM ARCHITECTURE



WSSFC-ATH-H5.PNG

DIMENSION DRAWING OF WIRELESS SENSOR (Unit: mm)



WSSFC-ATH-H6.PNG

RECOMMENDED BATTERIES

E91 AA Alkaline battery



- 18 .. + 60 oC working temperature
- 10-year shelf life
- 3000 mAH Capacity
- Price: 1X

L91 AA Lithium battery



- 40 .. + 60 oC working temperature
- 20-year shelf life
- 3500 mAH Capacity
- Price: 3.5X

WSSFC-ATH-H7.PNG



WSSFC-ATH-H8.PNG

ORDERING INFORMATION

ITEM CODE	DESCRIPTIONS
WSSFC-ATH-9-11	Sigfox sensor with Integral Humidity & Temperature sensor with sintered metal protection filter, Pre-Calibrated, Internal antenna, Type AA battery 1.5VDC, IP67, RC2-RC3-RC4-RC5 zones
WSSFC-ATH-8-11	Sigfox sensor with Integral Humidity & Temperature sensor with sintered metal protection filter, Pre-Calibrated, Internal antenna, Type AA battery 1.5VDC, IP67, RC1-RC6-RC7 zones
WSSFC-ATH-9-12-300	Sigfox sensor with Integral Humidity & Temperature sensor with sintered metal protection filter, Remote type 300mm cable, Pre-Calibrated, Internal antenna, Type AA battery 1.5VDC, IP67, RC2-RC3-RC4-RC5 zones
WSSFC-ATH-8-12-300	Sigfox sensor with Integral Humidity & Temperature sensor with sintered metal protection filter, Remote type 300mm cable, Pre-Calibrated, Internal antenna, Type AA battery 1.5VDC, IP67, RC1-RC6-RC7 zones

DAVITEQ TECHNOLOGIES INC

No.11 Street 2G, Nam Hung Vuong Res., An Lac Ward, Binh Tan Dist., Ho Chi Minh City, Vietnam

+84.28.6268.2523 / 6268.2524

info@daviteq.com

www.daviteq.com

JAN-2021 | Doc No: WSSFC-ATH-DS-EN-10