lagreto[®]



www.agreto.com

AGRETO Acre Meter AgriCounter Drive

Applications:

- Electronic acre meter for machines with support / gauge / stabilizer wheel
- Distance counter for transport vehicles
- Ideal for community and rental machines

Technical details:

- Activation by rotation of the counter
- No external sensor necessary
- Counts the number of rotations and optionally also the operating hours
- Display of the distance (km) or area (ha)
- Setting the wheel circumference and working width
- Adjustment of the necessary intensity of movement for activating the counting process
- Large, permanently switched on LCD display
- Six-digit display with 11 mm high digits
- Robust, one-piece plastic housing, protection class IP69k (pressure washer resistant)
- Tamper-proof by sealing the housing screws zeroing, adjustment of settings and battery change only by visible injury of the seal possible
- Powered by 2 AAA batteries, battery life with standard batteries approx. 3 years
- Dimensions: 93 x 52 x 33 mm (WxDxH)
- Scope of delivery: Counter, 2 batteries, 5 lead seals, mounting material, manual
- Made in Austria, 5 years warranty

Benefits:

- Simple, reliable distance / area counter
- Exact recording with 3-axis sensor
- Determining distance /area and operating hours together with one device
- Fair billing base according to real use
- Optimization of service intervals for operating units
- No manipulation possible by the user





