


FUEL LEVEL SENSOR FOR INDUSTRIAL APPLICATIONS



SKU: CAP10CN

SMART FUEL LEVEL SENSOR PulseCAP10 4-20mA Output




CAP10CN-H1.PNG

CAP10CN is industrial version of PulseCAP10, designed for industrial applications like generator, stationary fuel tank in factory, building, construction site...CAP10CN has 4-20mA output or RS485/ModbusRTU output, can be connected easily to any industrial devices like PLC, IoT Gateway, iConnector... CAP10CN has very high accuracy 0.1% of span, can be used for tank up to 30.000 liters volume.

- ✓ **99.9% ACCURACY**
Patented digital capacitance measuring technique PulseCAP10 of Daviteq allow high accuracy
- ✓ **EASY CALIBRATION**
Easy calibration for any fluid by just a button
- ✓ **INDUSTRIAL OUTPUT SIGNALS**
Output 4-20mA or RS485/modbusRTU for easy connecting to PLC, controller, SCADA, BMS...
- ✓ **SHORTEN TO 100MM ONLY!**
Allow to cut as short as 100mm length
- ✓ **EXTEND UP TO 4000MM**
Easy extend to 4000 mm by adding extension probes

SMART FUEL LEVEL SENSOR PulseCAP10 RS485



CAP10CN-H2.PNG

DAVITEQ TECHNOLOGIES INC

No.11 Street 2G, Nam Hung Vuong Res., An Lac Ward, Binh Tan Dist., Ho Chi Minh City, Vietnam

+84.28.6268.2523 / 6268.2524

info@daviteq.com


www.daviteq.com

JAN-2021 | Doc No: CAP10CN-DS-EN-10

SPECIFICATION

Sensor length	standard 1500mm, extend to 4000mm (by extension probe) or cut down to 100mm
Output	4-20mA output (with 250 ohms precision resistor), or RS485/ModbusRTU
Power supply	8..50VDC
Consumption	max 35mA
Working pressure	-1 .. 2 barg
Working temperature	-40 oC .. + 85 oC
Accuracy	+/- 0.1% of span (at 25 oC)
Temperature drift	< + 0.03% of span per 10oC
Resolution	1/1000 of span
Sensor materials	Alloy & Engineering plastic
Electrical connection	connector M12 (matched connector and cable must be ordered seperately)
Housing	Cast alumium, IP67 protection
Process connection	Plastic flange
Standard accessories	flange, o-ring, gasket, protection covers, self-tapping screws, twisted seal
Certification	CE-Marking per EN61236-1 (with test report)

PulseCAP10 on STATIONARY TANK

CONNECT TO WIRELESS BRIDGE
SIMPLY REPLACE RS485 CABLE

DAVITEQ TECHNOLOGIES INC

No.11 Street 2G, Nam Hung Vuong Res., An Lac Ward, Binh Tan Dist., Ho Chi Minh City, Vietnam
 +84.28.6268.2523 / 6268.2524
 info@daviteq.com www.daviteq.com


JAN-2021 | Doc No: CAP10CN-DS-EN-10

Connect with any PLC, HMI or IOT PLATFORM




CAP10CN-H5.PNG

SMART FILTERED FOOTER for STABLE MEASURING




CAP10CN-H6.PNG

PulseCAP10 Package includes



CAP10CN-H7.PNG

PulseCAP10 DIMENSION DRAWINGS



CAP10CN-H8.PNG

ORDERING INFORMATION

ITEM CODE	DESCRIPTIONS
CAP10CNC1500F	Fuel Level Sensor PulseCAP10CN, M12-Female connector, calibration by button and LED signal indicator, extension up to 4000mmm, factory calibrated by standard Diesel, L = 1500mm, output 4-20mA, with accessories, no cables, for industrial applications
CAP10CNR1500F	Fuel Level Sensor PulseCAP10CN, M12-Male connector, calibration by Modbus tool on PC, extension up to 4000mmm, factory calibrated by standard Diesel, L = 1500mm, output RS485/ModbusRTU, with accessories, no cables, for industrial applications
CAP10EXT0500	Extension Probe for CAP10, L=500mm
CAP10EXT1000	Extension Probe for CAP10, L=1000mm
CAP10EXT1500	Extension Probe for CAP10, L=1500mm
ACCESSORIES	
2M-MM12CAB4x0.25	M12 4pin Male assembly connector with Soldering terminals and coding A and Control Cable Cu/PVC/OS/PVC 4x0.25mm ² , L=2m, Rohs, Shield 80%
2M-FM12CAB4x0.25	M12 4pin Female assembly connector with Soldering terminals and coding A and Control Cable Cu/PVC/OS/PVC 4x0.25mm ² , L=2m, Rohs, Shield 80%
5M-MM12CAB4x0.25	M12 4pin Male assembly connector with Soldering terminals and coding A and Control Cable Cu/PVC/OS/PVC 4x0.25mm ² , L=5m, Rohs, Shield 80%
5M-FM12CAB4x0.25	M12 4pin Female assembly connector with Soldering terminals and coding A and Control Cable Cu/PVC/OS/PVC 4x0.25mm ² , L=5m, Rohs, Shield 80%
10M-MM12CAB4x0.25	M12 4pin Male assembly connector with Soldering terminals and coding A and Control Cable Cu/PVC/OS/PVC 4x0.25mm ² , L=10m, Rohs, Shield 80%
10M-FM12CAB4x0.25	M12 4pin Female assembly connector with Soldering terminals and coding A and Control Cable Cu/PVC/OS/PVC 4x0.25mm ² , L=10m, Rohs, Shield 80%
RS485-FM12-USB-1	RS485/USB multi-purpose Configuration cable with connector m12 male, female and flying leads, with Power adapter 12VDC/2.0A
CAP10PROTECTSET	CAP10 protection cover set
CAP10PARTSKIT	CAP10 parts kit
CAP10INSUFLANGE	CAP10 plastic flange
CAP10HOUSCOVER	CAP10 housing protection cover
CAP10CNTCOVER	CAP10 connector protection cover
CAP10FOOTER-001	CAP10 filtered footer
CM-CAP10LOWERGASKET2	CAP10 rubber gasket
CAP10BLINDCAP	CAP10 blind cap