



Features

- IP68 Wash down design
- Completely stainless steel housing
- Red LED display
- 1/6,000,1/15,000 display division selectable
- KG/LB selectable weighing mode
- HI/LO/OK weight checking with choice of variety alarm
- Weight and times accumulation, full tare, pre-tare ,zero tracking,
- Keyboard calibration,
- Auto power off selectable
- Easily adjusted leveling feet for stability of the scale

Options

Rear display

Specification

MODEL	CAPACITY	DIVISION
SS-3kg	3 kg	0.5 g
SS-6kg	6 kg	1g
SS-15kg	15 kg	2 g
SS-30kg	30 kg	5 g

Accuracy: 1/6,000, 1/15,000 Class III

Power supply : 6VDC/4Ah rechargeable battery

Working temperature: from -5 degree C to +35 degree C

Storage temperature: from -25 degree C to +50 degree C

Net/ Gt. 3.6kg/unit

Pan size: 190x230mm

SCALE OPERATES FULLY SUBMERGED IN WATER!!

A truly waterproof scale with IP68 rating certified by SGS

The scale features Stainless steel construction for the exterior surfaces , top plate and buttons.

It has an easily read bright red display which is great if the lighting is less than perfect where it is being used.

There is a rear display as well.

Functions supported are :-

- . Full range tare
- . Parts Counting
- . Over /under checking

For this latter feature the user can set in high and low values to use it as a check weigher.

For power the scale runs on its internal rechargeable battery pack , and in the base there is a compartment that houses a power cord that is used for recharging the internal battery from a mains power supply.

There is a variable power down timer which can shut the scale down to save power if it is left unused for a prolonged period.

The auto shut down period is selectable by the user.

If the unit is used on mains power all the time, the power down timer can be disabled to have continuous operation of the scale.

A battery condition indicator is provided on the front panel display so you can immediately see how much power is left in the battery