APPLICATION

"bun THERMO" is a water proof (IP68) temperature recorder and alarm system. It is powered by 2 replaceable AA batteries for up to 10 years and connects directly to Wi-Fi.

More than an accurate meter and a reliable logger, "bun THERMO" is also a cloud-based alarm system.

All setting parameters like measurement intervals, upload intervals, and minimum and maximum allowed temperature thresholds can be set through a web-based application on any platform. It sends out email and text message alarms as soon as any temperature exceeds or falls below pre-set limits. It also provides access to the records history, graphs and periodical reports. Its hardware and software installation is very easy and does not require any specific tools or applications.



GENERAL SPECIFICATIONS

Built in sensors		Temperature	
Temperature measurement range	°C	°C -25 to +70	
	°F -13 to +160		
Upload temperature range*	°C	°C -5 to +70	
	°F	20 to +160	
Temperature measurement accuracy	°C	± 0.3 (down to ± 0.2 by order) (± 0.55 °F)	
Power supply		2 x AA replaceable batteries	
Protection class		IP 68	
Compliances		IEEE 802.3, EN 61326-1, EN 61010, EN 12830,	
		FCCID: 2AHMR-ESP12F, CE, ROHS, HACCP	
Battery life*		Up to 10 years	
Upload intervals		One hour to once a week (or on demand)	
Record intervals		1 minute to 120 minutes (down 2 sec. by order)	
Interface		Wi-Fi - IEEE 802.3 – 2.4 GHz	
Max. number of internal records		16,384 – Automatic cloud sync and replace	

*Upload temperature range is the ambient condition required for the device to stay fully operational. These operations include being able to connect and sync with the cloud and send out alarms. However, the device can continue recording the data in its internal memory while in temperature measurement range.

*Depends on reading and upload intervals and environmental conditions. Battery life is more than 10 years in a standard set up. (Standard set up is room temperature 20°C measurement every 15 minutes upload every 48 hours).

AMBIENT CONDITIONS			
Storage temperature	°C	-25 to +75	

DIMENSIONS		
Diameter (max.)	L	mm 80.0
Height (max.)	Н	mm 34.5

KEY FEATURES



Direct Wi-Fi connection



Access to your records on all devices



Waterproof & washable



Up to 10 years of battery life



Push alarm for out of range registration





Graphs, reports & detailed records



Email & text message alarms



Cloud storage For +20 years

Loggerflex smart devices Ltd. 2-3304, Cambie St. Vancouver, BC V5Z 2W5 Canada

info@Loggerflex.com www.loggerflex.com

Tel.: (604) 210 22 42 Toll free: +1 888 365 88 80





