

TESTBOY 50

Brake fluid tester DOT 4

The Testboy 50 is a handy testing pin which can test the brake fluids DOT 4 in seconds. Five LEDs precisely indicate the water content in brake fluids manufactured based on glycol. Thereby, it is suitable for quick checking during the order acceptance in car workshops.

How you benefit:

- | Checking brake fluids DOT 4
- | Illuminated measurement probes
- | Long service life, as acid and alkali-resistant

Specifications

Technical Data	TESTBOY 50
Display	Optical via 5 LEDs
Measurement Range	DOT 4
Dimension	152 x 23,5 mm
Weight	40 g
Colour	Black
Scope of Delivery	Incl. battery
Power Supply	1 x 12 V, type V23
Protection	IP 40
Standard	IEC/EN 61010-1 (DIN VDE 0411)

